


Client/Electrician to supply the ceiling anchor required to hang the fixture.



## **Instructions**


All wall and ceiling fixtures are to be installed by a qualified electrician, do not attempt to install any products unless you are qualified to do so.

1. Unbox and check all components prior to assembly/installation.
2. Please refer to the rear of the page for further details on canopy installation.
3. Feed the flex and wire support through the shade and o-rings, prepare the canopy and ceiling anchor for installation.
4. This fixture weighs 10kg. Please ensure the ceiling anchor is attached into a structural element in the ceiling that is certified to support this weight. Please also ensure the correct fasteners are used.
5. Fully install the canopy to the ceiling and fasten the flex and support wire at the preferred hanging height, space the o-rings at equal distances along the length of the flex.
6. This light is supplied with a 11w dimmable LED globe, if you are substituting the globe please select a similar globe specification. Please note that for all international orders (excluding New Zealand) the globe is not supplied, please source a globe with similar specifications.

# Oak Large


## Installation Guide

### Canopy Mounting




1.

Remove magnetically attached Cosmetic Plate, taking care not to damage surrounding lip.




2.

Undo three screws and remove *Tool Plate*.




3.

Fix Canopy Shell to ceiling through 5mm slots (fasteners not included)




4.

Connect mains power supply and earth connection to the canopy terminal block.




5.

Slide Cosmetic Plate and Tool Plate onto flex. Then install Canopy Cord Grip onto flex.




6.

Connect flex into canopy terminal block.



7.


Reinstall Tool Plate.




8.

Reinstall Cosmetic Plate.


### Mounting Options



Standard



Flush Trimless\*\*  
(Bracket Not Supplied)



Flush Recessed\*\*  
(Bracket Not Supplied)

### Safety Precautions

- All products are to be installed by a certified electrician.
- Please refer to the instructions and canopy mounting stages for the installation of the fixture.
- Please do not modify or adjust any fixture in a way that is not clearly stated or intended.
- All lighting products are intended solely for indoor use.
- When switching out light globes or cleaning the product please ensure the power is OFF and the globe is not hot.
- Ross Gardam™ is not responsible for any damages caused by not following the provided instructions.

For further information such as care and maintenance, product overviews and disclaimers, please visit our website. Please don't hesitate to contact us directly if you have any questions and enquiries at [support@rossgardam.com.au](mailto:support@rossgardam.com.au)



60W MAX.,A.C.,50Hz, 220-240V